






## 8. POWER CONNECTOR SEALING




### 8.1 P6L/P6C Power connecting sealing

POWER CONNECTOR SEALING	PROCEDURE	DESCRIPTION
		 <p>Seal Cover</p> <p>Seal Cover</p> <p>Screw Base</p> <p>Seal Screw</p>
	STEP 1	 <p>Power Connector</p>
	STEP 2	 <p>Power Cable</p>
	STEP 3	 <p>Sealing Cover</p> <p>Sealing Screw &amp; Screw Base</p>
	STEP 4	



**9. PROGRAMMING PORT SEALING**

**9.1 P6L/P6C PROGRAMMING PORT SEALING**

PROGRAMMING PORT SEALING	PROCEDURE	DESCRIPTION
		 <p>Programming Port Cover</p> <p>Screw Base</p> <p>Seal Cover</p> <p>Sealing Screw</p>
	STEP 1	 <p>Programming Port</p>
	STEP 2	 <p>Installation of Programming Port Cover</p> <p>Sealing Screw &amp; Screw Base</p>
	STEP 3	